



SERVICE NEWS

Status: Released

Brief Description: *	General Safety Information	Issued By:	Atlas Copco Technical Service - LHD
Product Types: *	LHD Loaders & Trucks	Issue Date: *	06/24/2010
Service News #:	100624-972		
Model: *	General	Replacement Part #:	N/A
Part Description:	N/A	Replacement Part Description:	N/A
Part #:	N/A	Primary Use:	N/A
Safety Issue:	No	Reimbursement:	N/A
Response Required:	No		
Reason: *	General Safety Information For All LHD Products		
Parts Required:	N/A	Tools Required:	N/A

Text

A mining machine has many components and implements that are controlled by a hydraulic system, either directly or indirectly. Before working on or inspecting any part of a mining machine, it is important that the individual knows how the components move and are controlled by the hydraulic system components including the respective control circuits.

Before working on or inspecting any component, it must be physically constrained from any movement that could cause injury to the worker. The worker must be alert to not placing any part of his/her body where movement of a component could cause injury, unless that component is physically constrained from movement, if the hydraulic system fails, is disconnected, or is signaled to cause movement.

It must also be recognized that there are occasions where component and or vehicle movement may react to the release of potential energy. Where applicable it must be confirmed that all measures are employed to ensure that any and all sources of potential energy are released and/or physically restrained.

It is also the responsibility of those involved to insure that all local, state and federal safety regulations are followed, prior to, and during any work or inspection.

For More Information, Please Contact:

Dale Harnish
Technical Manager, LHD
Phone: (303) 217-2817; Fax: (303) 217-2840
Cell: (303) 506-9983

List of Atlas Copco Wagner Models Applicable to Service News 100624-972

E-988B	MT-444	ST-1010
EST-05	MTF-28	ST-1020
EHST-1A	MT-2000	ST-1030
EMT-422	MT-2010	ST-1500
EMT-439	MT-5000	ST-1520
EST-2D	MT-5010	ST-1530
EST-3.5	MT-5020	ST-1800
EST-5B	MT-6020	ST-1810
EST-6C	MTT-415-15	ST-600LP
EST-6CN	MTT-415S	ST-700
EST-8A	MTT-420-27A	ST-710
EST-8B	MTT-420-27B	UT-42
FB-645	MTT-F17-145	UT-45A
FB-650	MTT-F20-24	UT-45AS
HST-05	SST-2.5	UT-45B
HST-1A	ST-13	
LMTT-414S	ST-15Z	
LST-5	ST-1.3A	
LST-5-14X	ST-1.3AS	
LST-5-25X	ST-1.5	
LST-5S	ST-2	
LST-5S-14X	ST-2D	
LST-5S-20X	ST-2DR	
LST-5S-25X	ST-2DS	
MM-400	ST-2G	
MT-406	ST-2LS	
MT-408	ST-3.5	
MT-411-30	ST-3.5R	
MT-413	ST-5A	
MT-416	ST-5AS	
MT-420	ST-5B	
MT-420B	ST-5C	
MT-420N	ST-5DS	
MT-422	ST-5H	
MT-425	ST-5R	
MT-425	ST-6C	
MT-426	ST-6CN	
MT-426-30	ST-6CNR	
MT-426-42	ST-6CR	
MT-426B	ST-6L	
MT431	ST-7	
MT431B	ST-7.5Z	
MT433	ST-8	
MT436	ST-8A	
MT-436B	ST-8B	
MT-436BR	ST-8BR	
MT-437	ST-8C	
MT-439	ST-1000	